

TECHNICAL DATA SHEET

PHOS-PREP® PP 996 Aluminium Accelerator

Application:

PHOS-PREP® PP 996 Aluminium accelerator is added to process solutions where by additional etching of the aluminium or zinc based surface is required to aid the removal of natural oxides that may be present on the substrate

Instructions for use:

PHOS-PREP® PP 996 Aluminium accelerator is required at 0.1% to aid removal of the oxide on the surface to ensure satisfactory preparation and maintain adhesion as and when required

Control:

Manual control by adding to PHOS-PREP PP® 971 T / PP 992 / PP 995 at 0.1% to aid removal of the oxide on the surface of aluminium to ensure satisfactory preparation and maintain adhesion

Product safety data sheet: